


# User Manual

## Scales of TMX series

Manual number:  
ITKU-36-06-09-11-A



## Terminal E2R Ewidencja v. 1.1.6.119



### MANUFACTURER OF ELECTRONIC WEIGHING INSTRUMENTS

RADWAG 26 – 600 Radom 28 Bracka Street - POLAND

Phone +48 48 38 48 800, phone/fax. +48 48 385 00 10

Selling department +48 48 366 80 06

[www.radwag.com](http://www.radwag.com)

SEPTEMBER 2011

## TABLE OF CONTENTS

<b>1. INTENDED USE</b> .....	<b>6</b>
<b>2. PRECAUTIONS</b> .....	<b>6</b>
<b>3. WARRANTY CONDITIONS</b> .....	<b>6</b>
<b>4. MAIN DIMENSIONS</b> .....	<b>7</b>
<b>5. DESCRIPTON OF CONNECTORS</b> .....	<b>8</b>
<b>6. UNPACKING AND ASSEMBLY</b> .....	<b>9</b>
<b>7. GETTING STARTED</b> .....	<b>9</b>
<b>8. LOGGING ON</b> .....	<b>10</b>
<b>9. SCALE WINDOW DISPLAY</b> .....	<b>11</b>
9.1. View .....	11
9.2. Buttons' functions .....	12
<b>10. WEIGHING PROCEDURE</b> .....	<b>12</b>
10.1. Tarring .....	13
10.2. Hand operated tare value entering .....	14
10.3. Zeroing of scale .....	14
10.4. Weighing on two range scales .....	15
<b>11. WINDOW NAVIGATION</b> .....	<b>15</b>
<b>12. PRODUCT CHOICE</b> .....	<b>17</b>
12.1. Choosing a product by name .....	17
12.2. Choosing a product by code .....	19
<b>13. CHOICE OF A CONTRACTOR</b> .....	<b>19</b>
13.1. Contractor choosing by name .....	20
13.2. Contractor choosing by code .....	21
<b>14. CHOOSING A PACKING</b> .....	<b>22</b>
14.1. Choosing a packing by name .....	22
14.2. Choosing a packing by code .....	23
<b>15. STORE CHOOSING</b> .....	<b>24</b>
<b>16. LOT CHOOSING</b> .....	<b>26</b>
<b>17. LOT 2 CHOOSING</b> .....	<b>27</b>
<b>18. QUANTITY NUMBER CHOOSING</b> .....	<b>27</b>
<b>19. DATABASES</b> .....	<b>28</b>
19.1. Access to databases edition .....	28
19.2. Operators' database .....	28
19.2.1. Adding an operator .....	29
19.2.2. Editing an operator .....	31
19.2.3. Eliminating an operator .....	32
19.2.4. Operator's authority .....	33
19.3. Base of products .....	34
19.3.1. Adding products .....	34
19.3.2. Product's editing .....	37
19.3.3. Product eliminating .....	38
19.4. Contractors' base .....	38
19.4.1. Adding a contractor .....	38
19.4.2. Contractor's edition .....	40
19.4.3. Contractor's elimination .....	41
19.5. Base of packages .....	41
19.5.1. Adding a packing .....	41
19.5.2. Packing's edition .....	42
19.5.3. Eliminating a packing .....	43
<b>20. COUNTING PIECES</b> .....	<b>43</b>
20.1. Enabling working mode .....	43
20.2. Setting reference unit mass .....	45

<b>21. TRANSACTIONS</b> .....	<b>46</b>
21.1. Starting working mode.....	46
21.2. Starting a transaction.....	47
21.3. Continuing a transaction.....	49
<b>22. STATISTICS</b> .....	<b>50</b>
<b>23. WEIGHING RECORDING</b> .....	<b>51</b>
<b>24. PROGRAMMABLE BUTTONS</b> .....	<b>52</b>
<b>25. LOGGING OFF</b> .....	<b>53</b>
25.1. Logging off.....	53
25.2. Change-logging .....	53
25.3. Switching off a terminal .....	54
<b>26. CHECKWEIGHING THRESHOLDS</b> .....	<b>55</b>
<b>27. PROGRAM'S OPTIONS</b> .....	<b>55</b>
27.1. Weighing parameters .....	55
27.2. Operators.....	56
27.2.1. Operator's edition .....	57
27.2.2. Log on procedure .....	57
27.2.3. Authorization.....	59
27.3. Devices.....	60
27.3.1. Scales.....	61
27.3.2. Printer .....	63
27.3.3. CGM – Apparatus for testing conformation .....	66
27.3.4. Output mode .....	67
27.4. Reports.....	69
27.4.1. Date .....	70
27.4.2. Laps.....	71
27.4.3. Print monitoring .....	75
27.4.4. Export to a file.....	77
27.4.5. Programme closing.....	77
27.5. Others.....	77
27.5.1. Interface view .....	78
27.5.2. Buttons' functions .....	85
27.5.3. Language.....	88
27.5.4. Application closing.....	89
27.6. Alibi.....	90
27.6.1. Enabling write memory Alibi .....	92
27.6.2. Deleting a measurement of memory Alibi.....	92
27.6.3. Export measurements alibi to a csv file.....	93
27.6.4. Filter.....	93
27.7. IN/OUT configuration.....	94
27.7.1. Inputs configuration .....	94
27.7.2. Outputs configuration .....	95
27.7.3. Other options .....	96
<b>28. CONFIGURATOR PROGRAM</b> .....	<b>97</b>
28.1. Basic Configuration .....	97
28.2. External configuration.....	99
<b>29. WEIGHING PARAMETRES SETTING</b> .....	<b>102</b>
29.1. Weighing Server program starting.....	102
29.2. List of software menu .....	103
29.3. Parameters of scale software .....	103
29.3.1. Readout of parameters.....	103
29.3.2. Save changes procedure.....	103
29.4. Setting a filtering level .....	104
29.5. Median filter .....	104
29.6. Autozero function.....	105
29.7. Scale software settings.....	106

29.8. Closing WeighingServer program.....	107
<b>30. ERROR MESSAGES.....</b>	<b>107</b>
<b>31. LABEL DESIGNING.....</b>	<b>107</b>
31.1. Label pattern making.....	108
31.2. Inventory of variables:.....	111
<b>32. DIAGRAMS OF CONNECTION CABLES.....</b>	<b>113</b>
32.1. USB cable (adapter).....	113
32.2. USB printer cable.....	113
32.3. RS232 printer cable.....	114
32.4. Ethernet cable.....	114
32.5. RS232 terminal – computer cable.....	114
32.6. RS232, RS485 cable – colours.....	115
32.7. RS232C cable – colours.....	115
<b>33. CONNECTORS.....</b>	<b>115</b>
33.1. RS232, RS485 connector.....	116
33.2. Ethernet connector.....	116
33.3. USB connector.....	116
33.4. RS232C connector.....	116
<b>34. SPECIFICATION OF ADDITIONAL MODULES.....</b>	<b>117</b>
34.1. Weighing module MW-02.....	117
34.1.1. Module technical specification.....	118
34.1.2. Weighing platform signal wires colours.....	118
34.1.3. Weighing platform connecting.....	119
34.1.4. The way of installing inside PUE 5.....	121
34.2. Additional 8 inputs / 8 outputs module.....	122
34.2.1. Technical specification.....	123
34.2.2. Installing method in PUE 5 terminal.....	123
34.2.3. I/O diagram.....	124
34.2.4. Description of input output wires PT0082:.....	124
34.3. WE 4 - 4 inputs / 4 outputs module.....	125
34.3.1. Technical specification.....	125
34.3.2. Colours of cables for I/O PT0083:.....	126
34.3.3. Installing method in PUE 5 terminal.....	126
34.4. Analogue output module AN series.....	127
34.4.1. Technical specification.....	127
34.4.2. The way of installing inside PUE 5.....	127
34.4.3. Configuration of work modes of analogue modules.....	128
34.4.4. Connections to AN module.....	129
34.5. Profibus interface DP V1.....	130
34.5.1. Technical specification.....	130
34.5.2. Colours of wires.....	130
34.5.3. The way of installing inside PUE 5.....	130
<b>35. ADDITIONAL EQUIPMENT.....</b>	<b>132</b>
<b>36. TECHNICAL PARAMETERS.....</b>	<b>133</b>
<b>37. APPENDIX A – SETTING A BARCODE SCANNER.....</b>	<b>134</b>

## **1. INTENDED USE**

Scales of TMS series with TERMINAL E2R EWIDENCJA are intended to be used for measuring and at the same time recording the data in local database or on server. The application is especially important when the weighed products are not directly related one to another by any common data or they are not a part of the weighing process with its beginning and end, for example deal or order. The net of scales connected together enables transmitting the measurement results to the main database installed on server.

## **2. PRECAUTIONS**

- A. Please, read carefully this user manual and use the device according to its intended use;
- B. Weighed loads should be placed in most possible central part of scale pan;
- C. Do not clean the device with agents causing corrosion;
- D. Gross mass of goods loaded on weighing pan should be lower than maximal capacity of the scale;
- E. Do not leave heavy loads on the pan for long time;
- F. In case of failure, scale power supply should be disconnected immediately;
- G. Devices that are to be withdrawn from usage should be utilized according to the law regulations.

## **3. WARRANTY CONDITIONS**

- A. RADWAG is obliged to repair or exchange those elements that appear to be faulty because of production and construction reasons,
- B. Defining defects of unclear origin and outlining methods of their elimination can be settled only in presence of a user and the manufacturer representatives,
- C. RADWAG does not take any responsibility in case of damages or losses caused by non-authorized or inappropriate production or service procedures,

D. Warranty does not cover:

- Mechanical failures caused by inappropriate maintenance of the device or failures of thermal or chemical origin or caused by atmospheric discharge, overvoltage in mains or other random events,
- Cleaning service.


E. Warranty expires after:

- Access by an unauthorized service,
- Intrusion into mechanical or electronic construction of unauthorized people,
- Removing or destroying protection stickers.

F. The detailed warranty conditions are specified in warranty certificate.


G. Authorized service line: +48 48 384 88 00  
ext. 106 or 107.

## 4. MAIN DIMENSIONS



*Main dimensions of PUE 5*

## 5. DESCRIPTION OF CONNECTORS



*Back side view of PUE 5*

*Connectors in standard version:*

- 1 *Strain gauge cable gland*
- 2 *USB connector*
- 3 *USB connector*
- 4 *RS232, RS485 connector*
- 5 *Ethernet connector*
- 6 *Power cord cable*
- 7 *ON/OFF switch*
- 8 *Glands of optional equipment (8IN/8OUT, 4IN/4OUT, RS485 via gland, additional platform, etc)*

### **NOTICE:**

All connectors can be used in any configurations.




## 6. UNPACKING AND ASSEMBLY

- A. Remove the scale from the packaging,
- B. Place the scale on even and hard surface far from heat sources,
- C. Scale should be levelled by turning levelling foot. Levelling is correct if air bubble is in central position of level indicator located on scale's base.



## 7. GETTING STARTED

- Turn on the scale pressing the **ON/OFF** switch on the back side of the terminal. Then Windows loading will start.
- After the starting procedure, the main window of TERMINAL E2 EWIDENCJA application will be displayed automatically.



### **Notice:**

*The main programme's window view can be changed by choosing suitable setting options.*

## 8. LOGGING ON


You have to log on every time you start the scale.

### **Caution:**

*Logging on is necessary in order to record weighing results and to choose article, contractor, wrappings, store, lot number from the database*

### **Procedure:**

- While in the main application window, press "log in", then this will appear:



- Press „Operator 1” , then the main window will appear and the information about the logged user will be shown in top-left corner of the application:

Logged operator : Operator 1 Login time: 12:14:05

**Caution:**

„Operator 1” has got the „administrator’s” authority, what makes a scale’s user have direct access to all the program functions. The application consists of four authority levels, which are described later in the manual.


In the information line the following can be found:

- Log off time - Time of user’s logging off or turning on terminal’s applications
- User’s name - User’s name and the time of logging
- Time of logging

## 9. SCALE WINDOW DISPLAY

### 9.1. View

The scale window is located in the upper right corner of the screen:



After the starting procedure the following symbols be displayed in scale’s window:


- precise zero indication
- measurement result is stable
- kg** - weighing unit
- weighing platform number

If the pan is unloaded and there is no zero indication – click the zeroing button.

## 9.2. Buttons' functions



Zeroing of scale





Tarring



Hand-operated tare entering

## 10. WEIGHING PROCEDURE

Put a load on the scale pan. When  appears the result can be read.  
In order to record the weighing result press:




### **Caution:**


*To save the weighing result operator must be logged on and product must be chosen from database first.*

In order to assure long-term operation and correct measurement results, follow the steps:


- Loads should be placed on the pan slowly and carefully in order to avoid mechanical shocks:




- Loads should be placed centrally on the pan (errors caused by eccentric weighing are outlined by standard PN-EN 45501 point 3.5 and 3.6.2):




- Do not load the pan with concentrated force:




- Avoid side loads, particularly side shocks should be avoided




### 10.1.Tarring

In order to get the net weight put the load on pan and press  when it is stable ( zero is indicated and **Net** symbol appears in top left corner of weighing window).



After placing a load on the weight pan net mass will be shown. Tarring is possible within the whole range of the scale. While tarring, remember that the maximum capacity of scale should not be exceeded.

After unloading product and packing from the pan the display shows the tarred value with “minus” sign:



**Notice:**

Tarring process cannot be performed while the display shows a negative or zero value. Then **Err3** will appear on weighing window display.

### 10.2.Hand operated tare value entering

It is also possible to enter a tare value by hand.

**Procedure:**

- While in main window press , and you will see the following window:
- Using number buttons enter the required value and accept it by clicking ,
- The scale returns to weighing mode. The inscribed value will be preceded by „-“,
- Tarring can be applied at any time during weighing.
- Use button to remove the previous value.



### 10.3.Zeroing of scale

Press in program’s weighing window to get zero indication. Symbols: and will appear.


Zeroing is equivalent to setting a new zero point interpreted by the scale as the precise zero point. Zeroing can be performed only when display is stable.

**Notice:**

Zeroing is possible only within the range of  $\pm 2\%$  of maximum scale's capacity. If the zero value is beyond this range, **Err2** message will be displayed.

### 10.4. Weighing on two range scales


Switching between the **I range** and the **II range** weighing appears automatically without operator's presence when I range maximum value is exceeded. Starting II range weighing is indicated by  $\rightarrow 2 \leftarrow$  symbol in the top left corner of the scale window. When loading is eliminated the indication returns to zero value. Until then the scale remains in the **II range**.



Switching between the **II range** and the **I range** takes place automatically after loading elimination, when the indication returns to AUTOZERO range and symbol  $\rightarrow 0 \leftarrow$  appears. Then II range symbol disappears and weighing is performed again with the accuracy of the **I range**.


## 11. WINDOW NAVIGATION

### MAIN PROGRAM'S WINDOW DESCRIPTION



- 1 - Information line
- 2 - Recorded weighing results window
- 3 - Mass bar chart
- 4 - Database of statistics
- 5 - Log off/log on button
- 6 - Weight window
- 7 - Choosing items from database buttons
- 8 - Programmable buttons

Choice window description/edition of database items





- 1 - Displayed items filtering fields
- 2 - Database items displaying window
- 3 - Sorting buttons
- 4 - Ten latest displayed items button
- 5 - Addition/edition/elimination database items button
- 6 - Change approval/refusal or selection buttons
- 7 - Rewinding chosen items buttons
- 8 - Filtering cleaning
- 9 - Information window




## Screen keyboard window



-  - Window clearing
-  - Cursor moving arrows

## 12. PRODUCT CHOICE

In the main program window the scale's user can choose product from database by name or code, as the picture shows:




To remove the selected product press .

### 12.1. Choosing a product by name

#### Procedure:

- Start product choosing by name procedure according to point 12 of the manual and you will see the following:




- Choose the demanded product, then the program will automatically return to main window, where the product's code and name will appear in appropriate fields:



- In case of large number of products in the database, user can search:
  - by code
  - by name
  - by EAN code of product

**As it is shown in the picture below:**



In order to eliminate filtering of code, name and EAN fields, press





## 12.2. Choosing a product by code

### Procedure:

- Enter the product choosing by code mode according to point 12 of the manual so you can see :




- Using the screen keyboard load the demanded product's code and accept it pressing  button.
- The program will automatically return to the main window, displaying code and name of the chosen product in appropriate fields.



## 13. CHOICE OF A CONTRACTOR

In the main application window scale's user can choose a contractor from database by code or product's name, according to the following picture:



To remove a contractor press .


## **CAUTION!**

*Contractor's choice window will be accessible after setting up its profile in the main application window, according to point 27.5.1 of the manual.*


### **13.1. Contractor choosing by name**

#### **Procedure:**

- Choose constructor choosing by name mode according to point 13 of the manual, then you will see the following:



- Press the required contractor's profile and the program will automatically return to the main window, displaying code and name of chosen contractor in appropriate fields:




- In case of large number of contractors in database, user can filter or search by:
  - contractor's code,
  - contractor's name

As it is shown in the picture below:



- Searching for contractor by code
- Searching for contractor by name


In order to eliminate code and name fields' filtering, press  button.

### 13.2. Contractor choosing by code

#### Procedure:

- Enter constructor choosing by code mode according to point 13 of the manual, so you can see the following:




- Using screen keyboard, load the required contractor's code, then accept it pressing  button.
- Program will automatically return to the main window, displaying the demanded contractor's code and name in appropriate fields.



## 14. CHOOSING A PACKING

In the main application window the user can choose a packing by its code or name as follows:



To remove a package press .


### **Caution!**

*Packing choosing window will be accessible after setting up its profile in the main application window, according to point 27.5.1 of the manual.*


### 14.1.Choosing a packing by name

#### Procedure:

- Enter choosing a packing by name mode according to point 14 of the manual, so you can see the following:




- Press required packing, then the program will return to the main window displaying code and name of the chosen packing




- In case of large number of packages in database user can filter or choose by:
  - code of packing,
  - name of packing,

**As the picture shows:**




- Searching packages database by code
- Searching packages database by name


In order to eliminate code and name fields' filter, press  button.

## 14.2.Choosing a packing by code

### Procedure:

- Enter choosing a packing by code mode according to point 14 of the manual so you can see the following:



- Using screen keyboard, enter the demanded code of packing and accept it pressing  button
- The program will automatically return to the main window displaying code and name of chosen packing in appropriate fields.



## 15. STORE CHOOSING

User can choose a source and target store according to following picture



To remove a store/warehouse press .


### **CAUTION!**

*Target and source store choosing window will be accessible after setting up its profile in the main application window according to point 27.5.1 of the manual.*

### **Procedure:**

- Choose source or target store, then you will see the following:





- Choose demanded store, then the program will automatically return to main window, displaying name of chosen store in appropriate field:




- In case of large number of stores in database, user can filter or search by:
  - store's code
  - store's name,

**As the picture shows:**




- Searching stores' database by code
- Searching stores' database by name

In order to eliminate code and name fields' filter, press  button.

## 16. LOT CHOOSING

Scale's user can load a lot number for each weighing. In order to do that, Press the button appropriate for loading a lot number in the main application window.




Lot/batch window can be cleared by pressing .

### **Caution!**

*Lot choosing window will be accessible after setting up its profile in main application window, according to point 27.5.1 of the manual.*

### **Procedure:**

- Load a lot number to keyboard window



- The program will automatically return to main window, displaying loaded lot number in appropriate field.



## 17. LOT 2 CHOOSING

User weight for each weighing can indicate the number of LOT 2.

Lot number	Lot 2 number

Procedure for defining the LOT is the same as in paragraph 16 of the instructions.

## 18. QUANTITY NUMBER CHOOSING

### Procedure:

In order to assign a weighting number which acts as a descriptive panel, press the main weight of responsibility for the introduction of a quantity.

wprowadzenie ilości sztuk

...

Then, with the numeric keypad enter any number.

←		
7	8	9
4	5	6
1	2	3
0	+/-	,
anuluj		ok

Entered number is displayed on the button and is stored in the weighing .


wprowadzenie ilości sztuk


10

## 19. DATABASES

### 19.1. Access to databases edition

#### Procedure:

- While in database choice window, press  button, then the following will be displayed:






### 19.2. Operators' database

#### **Caution!**

*Operators' database edition is accessible in the program's options for logged user who has the administrator's or advanced authority. Operators' database can be also edited while user's change-logging.*

#### Procedure:


- In order to edit operators' database, press ,
- Press  in operator's log off window.
- Press **Operators** button in option window



- Press **Operators' edition** button



- Access to operators' database window will be displayed:



### 19.2.1. Adding an operator

#### Procedure:

- Enter the operators choosing window according to point 19.2 of the manual, then press:





according to point 19.1 of the manual, then, the following will be displayed:

And as the picture shows:



- name\*** - operator's name field
- code\*** - operator's code field
- authority** - user's authority type
- set up password** - setting up user's password

\*) - filling in is obligatory

- Press text field or button  in order to load operator's data (code, name)




The buttons' functions:

-  - Approval of loaded new information
-  - Refusal of loaded new information

- After operator's code and name loading, set up authority level pressing a button below; choose an option from unrolled list:



- Set up operator's password, pressing . Using keyboard that appears on the terminal's screen, enter the password and accept it.

**Caution!**

*You have to enter identical password twice, otherwise information about error will be displayed:*



- In order to accept adding an operator press:



- In order to refuse adding an operator press:



**19.2.2. Editing an operator**



**Procedure:**

- Enter operators choosing window according to point 19.2 of the manual, choose an operator you want to edit, then, according to point 19.1 of the manual, press:



this is what will appear on the screen:

Complete the fields according to information in point 19.2.1 of the manual

- In order to accept all changes, press ,
- In order to refuse changes, press .

### 19.2.3. Eliminating an operator


#### Procedure:

- Enter operators choosing window according to point 19.2 of the manual, then according to point 19.1 press:



then the window will appear:




Accept eliminating an operator pressing: .




### 19.2.4. Operator's authority

*Operators' authority table*

		Administrator	Advanced	Standard	Basic
operations	logging on a terminal	accessible	accessible	accessible	accessible
	weighing (choice of variables)	accessible	accessible	accessible	accessible
	reports	accessible	accessible	inaccessible	inaccessible
	Min Max thresholds	accessible	accessible	inaccessible	inaccessible
	options setting	accessible	accessible	inaccessible	inaccessible
	weighing parameters	accessible	accessible	accessible	inaccessible
	switching off a terminal	accessible	inaccessible	inaccessible	inaccessible
contractors	closing the program	accessible	inaccessible	inaccessible	inaccessible
	adding	accessible	accessible	accessible	inaccessible
	editing	accessible	accessible	accessible	inaccessible
packages	eliminating	accessible	accessible	inaccessible	inaccessible
	adding	accessible	inaccessible	inaccessible	inaccessible
	editing	accessible	inaccessible	inaccessible	inaccessible
articles	eliminating	accessible	accessible	inaccessible	inaccessible
	adding	accessible	accessible	accessible	inaccessible
	editing	accessible	accessible	inaccessible	inaccessible
operators	eliminating	accessible	accessible	inaccessible	inaccessible
	adding	accessible	accessible	inaccessible	inaccessible
	editing	accessible	accessible	inaccessible	inaccessible
	authorization, way of logging on	accessible	inaccessible	inaccessible	inaccessible

 - accessible

 - inaccessible

## 19.3. Base of products

### 19.3.1. Adding products



















#### Procedure:




- Using product choosing by name button in main program window enter base of products, then, according to point 19.1 of the manual, press:



and this will appear:

Product creating:

Code		<input type="text"/>				
Name		<input type="text"/>				
EAN		<input type="text"/>				
Mass	<input type="text"/>			Tare [kg]	<input type="text"/>	
Price	<input type="text"/>			max [kg]	<input type="text"/>	
min [kg]	<input type="text"/>			Temperature	<input type="text"/>	
Usability time	<input type="text"/>			Label field edition		
VAT [%]	<input type="text"/>			Label	<input type="text"/>	
Cancel 						Add 


- press:  button or text field in order to load data.
- in order to accept adding a product press: ,
- in order to refuse changes press: .

## Fields to be completed:


- Name\*** - name of product
- Code\*** - code of product
- EAN** - EAN bar code of product
- Price** - retail price of product
- Mass** - net weight
- Tare** - tare weight
- Min** - product's min threshold
- Max** - product's max threshold
- Validity time** - No of validity days of a product after the day of weighing
- Temperature** - Storage temperature (text field)
- Edit Label Field** - This field can hold any information about the product
- VAT [%]** - Interest rate of VAT
- Label** - File selection box printed labels for the goods

\*) – filling in is compulsory


### **Notice!**

Using button  a barcode can be read directly from the label. A barcode scanner allows quick product selection provided it is described by EAN code field.


### *Editing the window of ingredients*







After pressing  a window appears in which additional information can be inscribed e.g.: ingredients. Every line (L1-Ln) can be printed separately, see additional information in ch. 31.2.










In order to add this field press  and then enter the text for the line.



The line is displayed in the window.



## Functions of buttons in the window:

	- Add a line
	- Edit a line
	- Delete a line
 	- Change line position
	- Cancel changes
	Confirm changes

### 19.3.2. Product's editing
















#### Procedure:

- Using choosing product by name button in the main program window enter base of products, then choose product to be edited, and according to point 19.1 of the manual press:



then the following will be displayed:

Product edition: Towar 1

Code	
<input type="text" value="1"/>	
Name	
<input type="text" value="Towar 1"/>	
EAN	
<input type="text" value="5901480002186"/>	
Mass	Tare
<input type="text" value="0.5"/>   	<input type="text"/>  
Price	max.
<input type="text"/> 	<input type="text"/>  
min.	Temperature
<input type="text"/>  	<input type="text"/> 
Usability time	Label field edition
<input type="text"/> 	<input type="text"/>
VAT [%]	Label
<input type="text"/> 	<input type="text"/> 
 	

Fill in the fields according to point 19.3.1 of the manual

- In order to accept changes, press
- In order to refuse changes, press



### 19.3.3. Product eliminating

#### Procedure:

- Using product choosing by name button in the main program window enter base of products, choose product to be eliminated, and then according to point 19.1 of the manual press:



chosen product will be eliminated.

### 19.4. Contractors' base

#### 19.4.1. Adding a contractor




#### Procedure:

- Using contractor choosing by name button in the main program window, enter contractors base, then according to point 19.1 of the manual press:



the following will appear:

The screenshot shows a software window titled "Contractor creating:". It contains several input fields and buttons. The fields are: "Code", "Name", "Post code", "Street", "TIN", "Post code", "Discount[%]", and "Label code". Each field has a small blue button to its right. At the bottom right of the window, there are two larger buttons: "Cancel" with a red prohibition sign and "Add" with a green checkmark.

- Press  button or text field in order to load data.
- In order to accept adding a contractor press: ,
- In order to eliminate changes press .

### Fields to be completed:

- Code\*** - product's code
- Name\*** - product's name
- Place of living** - contractor's place of living
- Street** - street and number
- TIN** - tax identification number
- Post code** - post code
- Discount [%]** - discount assigned for contractor
- Label code** - code of label printed for contractor

\*) - filling in is compulsory

## 19.4.2. Contractor's edition

### Procedure:



- Using contractor choosing by name button in main program window, enter contractors base, choose a contractor to be edited, then according to point 19.1 of the manual press:



then the following will be displayed:

A dialog box titled "Editing contractor : Contractor 1". It contains several input fields with labels on the left: "Code" (value: 1), "Name" (value: Contractor 1), "Town" (value: Radom), "Street" (value: Bracka 26), "VatNo" (value: 999-999-99-99), "Post code" (value: 26-600), "Discount[%]" (value: 10), and "Label code" (value: 1). Each field has a small blue button to its right. At the bottom right, there are two buttons: "Cancel" with a red prohibition sign and "Apply" with a green checkmark.

Complete the fields according to point 19.4.1 of the manual.

- In order to accept changes press ,
- In order to refuse changes press .



### 19.4.3. Contractor's elimination

#### Procedure:

- Using contractor choosing by name button in the main program window, enter contractors' base, choose a contractor to be eliminated and according to point 19.1 of the manual press:



chosen contractor will be eliminated from database.

### 19.5. Base of packages


#### 19.5.1. Adding a packing


#### Procedure:



- Using packing choosing by name button in the main program window, enter base of packing, then according to point 19.1 of the manual press:



the following will be displayed:

A screenshot of a software window for adding a packing. It features four input fields: "Name", "Code", "Barcode", and "Mass[kg]". Each field has a small blue button to its right. At the bottom right, there are "Cancel" and "Add" buttons. The "Add" button has a green checkmark icon.

- Press  button or text field in order to load data

- In order to accept adding a packing press: ,
- In order to refuse changes press: .

**The spaces' meaning:**

- Name\*** - name of packing
- Code\*** - code of packing
- Barcode** - bar code of packing
- Mass [kg]** - weight of packing

\*) - fill in obligatory


**19.5.2. Packing's edition**

**Procedure:**

- Using choosing a contractor by name button in the main program window, enter contractors database, choose a contractor to be edited, then , according to point 19.1 of the manual, press:



the following will be displayed:





The screenshot shows a software window with the following fields and values:

- Name: Packaging 1
- Code: 1
- Barcode: 123
- Mass [kg]: 0,15

At the bottom right of the window, there are two buttons: 'Cancel' (with a red prohibition sign) and 'Add' (with a green checkmark).

complete the fields according to point 19.5.1 of the manual.

- In order to accept changes, press: ,
- In order to refuse changes, press: .

### 19.5.3. Eliminating a packing

#### Procedure:

- Using choosing a packing by name button in the main program window, enter packages base, choose a packing to be eliminated and, according to point 19.1 of the manual, press:





chosen packing will be eliminated from database.


## 20. COUNTING PIECES

Standard software in weighing terminals PUE5 comprises an additional working mode – counting pieces. The database of weighings holds measurements in pieces of the same weight. If counting pieces is performed in an additional container it needs to be tarred before putting counting pieces into it.

### 20.1. Enabling working mode


#### Procedure:



- While in the main window press ,
- While in the operator logout window press ,
- Then press in sequence buttons:




In the interface window tick **Counting Pieces**. You will see .

In the interface window, select the **Operating modes** and **Counting pieces** tab, select **Active**.



- Press  2 times.
- The introduced changes are confirmed by pressing ,

The working mode is on when the pcs unit is on the display:



In the weighing window additional column **Pieces** appears apart from weighing in **g**.

Logged operator: Administrator. Logging time: 11:35:26

Time	Mas...	Pro...	Op...	Contr...	Pieces
1/11/2011 ...	3	Towar 1	Admi...	Kontrah...	0

## 20.2. Setting reference unit mass

The reference unit mass can be set by estimating single piece mass in the main program window using a function key attributed to this function. Settings are described in ch. 27.5.2 of this manual.

→T←		+0←	
Mass			
Piece mass	0 kg	▲▼	
Total mass	0.000 kg		
Quantity			
Quantity	100		

After zeroing the platform put pieces on the pan and inscribe the quantity in field **Number of Pieces**. Single piece mass is estimated automatically.

The reference unit mass can be also set in the assortment database. After opening the window below press the button next to the mass field as shown below.

Product edition: Towar 1

Code:

Name: Towar 1

EAN: 590148002186

mass: 0.5

tare:

max:

min:

Temperature:

Usability time:

Label field editor

WAT [%]:

Label:

Cancel  Apply

The third way of setting the reference mass is to inscribe its value in the field **Mass** in the window above.

## 21. TRANSACTIONS



PUE5 weighing terminals with the extended software version can operate in working mode transactions. The weighing process is connected with selling transactions – purchasing, production orders, servicing orders and stock management. A new transactions can be created on the terminal. It can be temporarily suspended or terminated.


### **Notice!**

The full functionality of the transaction mode comprising stock management, reports, supervising transactions can be obtained in the E2R Transakcje program in PC version.

### 21.1. Starting working mode



#### Procedure:

- While in the main window press ,
- While in the operator logout window press ,
- Then press in sequence buttons:




In the window of interface outlook tick **Transactions**. You will see  next to it.



- Press  two times.
- Confirm the introduced changes by pressing ,

## 21.2. Starting a transaction

There is button **new** in the main window to start a transaction.



Choose transaction type.



## Types of transaction:

### **M-M Transaction Between Warehouses**

- Moving a product from one warehouse to another.

### **SPR Sell**

- Transaction of selling that requires outlining of a contractor and a source warehouse.

### **ZAK Purchase**

- Transaction of buying that requires outlining of a contractor and a target warehouse.

The next step is to choose a contractor to be attributed to the transaction and a source or target magazine. When moving between warehouses contractors are not necessary. Only a source and target warehouses are required.


The screenshot shows a software window titled "Contractor Contractor 1". At the top, there is a "Filter" section with two input fields labeled "code" and "name". Below the filter is a list of contractors. The first entry is selected and highlighted in light blue, showing "code: 1" and "name: Contractor 1". To the right of the list are several navigation buttons: a search icon, a single right arrow, a double right arrow, a single left arrow, a double left arrow, and a single left arrow with a right arrow. At the bottom of the window, there are several control buttons: "sort by code", "sort by name", "List" (with a dropdown arrow), "Edit" (with a dropdown arrow), "Cancel" (with a red prohibition sign), and "Ok" (with a green checkmark).



## Accessible warehouses:


- Code 1** - **Sell**
- Code 2** - **Purchase**
- Code 3** - **Warehouse1**

After choosing all necessary parameters in the main program window detailed transaction information appears and a transaction symbol is attributed. All weighings in the transaction are attributed to a given unique symbol.




A transaction in progress can be terminated or completed using an appropriate button **break** or **end**. Suspending a transaction allows to postpone it until it is selected again. During a transaction is suspended other transactions can be created, continued or terminated.

To suspend a transaction press **yes** in the window below.



After a transaction is completed/closed new weighings cannot be performed within this transaction. Press **yes** to close the transaction.



### 21.3. Continuing a transaction

A transaction can be continued after pressing **continue** button in the main window.



From the list of transactions choose the one you want to continue and press **Ok**.



Until the transaction is closed it is accessible on the list of suspended transactions.

## 22. STATISTICS


All the statistic data is regularly updated after loading each measuring data to scale's database. Data interlock can be seen in bottom left corner of the main program window.

Global	
sum	0,000 kg
quantity	0
avarange	0,000 kg
min	0,000 kg
max	0,000 kg

Statistic data is updated globally irrespective of weighed product.

## 23. WEIGHING RECORDING

All weighing results are saved in MS SQL database, which is stored locally or on another weighing terminal or server.



After pressing SAVE button, weighing result will be displayed automatically in the chart. The last twenty weighings are present on the list.

All weighings are displayed in grams in the table. Additionally, user can sort certain columns increasingly or decreasingly, pressing chosen column's name.

In **Terminal E2R Ewidencja** user with administrative privileges have access to the preview, or removal of weighings made with the reports by stating the following area.


The window displays all recorded measurements. The **E2R SYSTEM** which is connected to the terminal window displays a few measurements only the current terminal.




The primary filter, the filter weights is presented as of the date - to date. By default, when you start windows are presented last two days.



After selecting the weighing and selecting edit and delete, the weighting will be awarded as an archive which means that it will not be presented in the report.



Jeżeli ważenie zostało odznaczone przypadkiem jako archiwalne to za pomocą funkcji edytuj i dodaj, możemy wyłączyć status archiwalne i od tej pory ważenie będzie prezentowane w raportach.



## 24. PROGRAMMABLE BUTTONS

In the main program window user can choose out of 5 optionally configured function buttons.



**Save** button's function can be transmitted to **F1-F5** buttons or switched off.



## 25. LOGGING OFF

**Log off** button in the main program window is used for logging off and switching off the terminal. The options are accessible if the logged user has got administrator's or advanced authority.


To exit the operator's log off window, Press:



### 25.1. Logging off

Log off function is used when a scale's user is finishing his work and the terminal is not switched off.

#### Procedure:

- In order to log off an operator press: ,
- Then press **Log off** button:



- Program will automatically return to its main window


#### **CAUTION!**

*All functions that are necessary for weighing recording are inaccessible until the next logging.*

### 25.2. Change-logging

Change-logging function is used when the first weighing terminal's user is finishing and next one is starting his work.

#### Procedure:

- In order to change-log an operator press: ,

- Then press **Change-log** button:




- List of accessible users will be displayed; after one of users is chosen, the program returns to its main window automatically.

### 25.3. Switching off a terminal


User can switch off a weighing terminal only if he is logged on.

#### Procedure:

- Press  in the main program window,
- Then press **Switch off terminal** button:



- Accept switching off terminal choosing **Yes**



- When the information „**It is now safe to turn off your computer**” is displayed, turn off scale’s power pressing **ON/OFF** which is located on the back side of terminal’s casing.

## 26. CHECKWEIGHING THRESHOLDS

In the main program's window user can see checkweighing thresholds' results (MIN,MAX) in a bar chart



Checkweighing thresholds data is taken from database of a product or programmed with function buttons described in point 27.5.2 of the manual.

## 27. PROGRAM'S OPTIONS

### Procedure:

- In order to enter program's options, user with administrator's or advanced authority must be logged on.

- Press  in program's main window,

- Press:  in log off operator window ,

### **CAUTION!**

*Changes made in the options must be approved in the main window by*

*button options* .

### 27.1. Weighing parameters


Setting up basic weighing parameters.

### Procedure:

- Enter program's options according to point 27 of the manual, then press:



- Window with weighing parameters will be displayed automatically



**Weighing Server** program configuration platforms connected by weighing module **MW02** is described in point 24 of the manual.

## 27.2. Operators

The option enables operators' edition and setting logging and authorization mode.

- Enter program's options according to point 27 of the manual, then press:





Then the window with accessible operator's options will be displayed:




### 27.2.1. Operator's edition

Edition, that is adding, changing or eliminating an operator has been described in point 19.2 of the manual.


### 27.2.2. Log on procedure


#### Procedure:



- Enter operator's options as instructed in point 27.2 of the manual, then press:



- Choose logging procedure:



Accessible option will be marked with .

- in order to accept loaded changes, press: ,
- in order to refuse changes, press: .


**Note that:**

- Select from list** - While logging, user chooses operator's name or code from database and has access to list of all operators
- Enter code operator** - While logging, user is supposed to enter operator's code; he does not have access to the list of operators
- During start** - Switching on the option can cause a situation that while weighing meter is starting, logging window, with list of accessible users or operator's code entering window (up to the setting) can open automatically. Entering incorrect data can result in starting main program's window with no user logged on

### 27.2.3. Authorization



#### Procedure:

- Enter operator's options as instructed in point 27.2 of the manual, then press:



- Choose authorization mode:



- In order to accept changes, press: 
- In order to refuse changes, press: 

**Note that:**

**Without authorization**

- In order to log on to a program, the user is supposed to enter chosen operator's password

**Password**

- While logging, password entering option is not active

**CAUTION!**

*If **Without authorization** and **Select from list** point 27.2.2 options are accessible at the same time, then user with subordinated authority can log on one of administrator's accessible profiles, which enables him to get access to most of program's options.*

**27.3. Devices**

**Devices** option enables devices' and connected to weighing terminal interfaces' edition.

**Procedure:**

- Enter program's options as instructed in point 27 of the manual, then press:



- Accessible devices will be displayed in the window below:



### 27.3.1. Scales


The option enables configuration of scales connected to the weighing terminal PUE5 with Ethernet or RS232/485.

#### Procedure:


- Enter devices option as instructed in point 27.3 of the manual, then press:



- Choose a scale to be edited then press:



- Set up appropriate data in parameter edition window



**Note that:**

- Description** - optional characteristics of scale
- Host** - host's IP address, default 127.0.0.1 specifies local computer's address,
- Port** - scale's port's number UDP/TCP
- Database id** - Platform's identification number
- LO Threshold** - LO threshold value for a particular platform.

LO Threshold parameter is related to the function of the automatic operation and control outputs.

For automatic operation, the measurement will not be saved to the database until an indication of not descend below the set threshold LO net.

### **27.3.2. Printer**

The option enables setting up labelling printer, which is installed in operational system. Additionally, it is possible to design a label for labelling printer and indicate saved label's file.

***CAUTION!***


*Now it is possible to set up a printer which prints labels after **Save** button in the main program's window has been pressed.*



**Procedure:**

- Enter devices options as instructed in 27.3 of the manual, then press:



- Then window of options accessible for designing and labelling printer prints setting will be displayed



- In order to accept changes press: 
- In order to refuse changes, press: 

**Note that:**

- |                              |   |
|------------------------------|---|
| <b>Name</b>                  | - Here you can choose labelling printer accessible in operational system. After printer has been installed in operational system, it will be added to the list automatically. |
| <b>Design labels</b>         | - Starting <b>Edytor Etykiet</b> program, used for label designing. To find out how the program works, read point 26 of the manual.   |
| <b>Label patterns file</b>   | - Indicating recorded on local disc file which will be the printed label's pattern.   |
| <b>Active label printing</b> | - Label printing switching on /off options  |



**Labels printing active while measurement recording**

Additional options associated with printing labels, which allows you to disable printing of labels during the recording. Enable option to print labels for each record.

**Printed labels**

Number of printed labels,  
- When set to 0, you write the part number printed labels.

**CAUTION!**

Printing labels is available after setting the printer, the standard label and select the two options **Active printing**.

- **Select the number of labels**

If the parameter number of printed labels is set to 0 then the record appears in the following dialog choose the number of labels. Entering any number of prints the same number of labels.



- **Select the label template**

When a label indicating the file, remember that before it is placed in the location: C:\Program Files\RADWAG\Terminal E2R Ewidencja\lab. Labels saved in this folder should have the extension \*. lb.



### 27.3.3. CGM – Apparatus for testing conformation


The program works with the apparatus to examine the conformation which allows registration at the weighing of information on meat quality. Hardware configuration requires you to set the communication port and speed.

#### Procedure:

- Enter devices option as instructed in point 27.3 of the manual, then press:



- You will then see a dialog where you can set the COM port to which the terminal device is connected.



### 27.3.4. Output mode

**Output mode** options allows you to configure the two selected outputs are activated depending on the current position in relation to 0, the threshold MIN and MAX currently selected item.


This feature can be used to control the process of dispensing the goods or alarm thresholds.

#### Procedure:

- Enter devices option as instructed in point 27.3 of the manual, then press:



- Then in the window, select one of the modes for thresholds and assign the starting threshold.




OUTPUT MODE	THRESHOLD	STATE OF MASS	Dosing rough	Dosing accurate
Threshold 1,2 to MIN	1	0 - MIN	1	1
Threshold 2 to MAX	2	MIN- MAX	0	1
Threshold 1 to MIN	1	0 - MIN	1	0
Threshold 1,2 to MAX	2	MIN- MAX	1	1
Threshold 1 to MIN	1	0 - MIN	1	0
Threshold 2 to MAX	2	MIN- MAX	0	1
0	1	0 - MIN	0	0
Threshold 1 from MIN	2	MIN- MAX	1	0
Threshold 1,2 from MAX	3	> MAX	1	1
0	1	0 - MIN	0	0
Threshold 1 from MIN	2	MIN- MAX	1	0
Threshold 2 from MAX	3	> MAX	0	1

**CAUTION !**

In the case of mode 3 release trigger outputs to turn off the third fret on the threshold dose MAX. Dosing process will be activated only when the mass reaches the platform MIN.

Thresholds can be attributed only to go free. In the case of occupied disable all the outputs assigned functions at the point **27.7.2**



After making changes to output mode, the new functionality will be allocated only to the newly selected item from the main program window. Select the product to test out.

## 27.4. Reports

The option enables preparing and printing the weighing results report or write a report on the terminal disk in a file format PDF, XLS or CSV.

### NOTE:


Versions of reports are described below 9.11.9.0. PUE5Reports.dll file reports is located at Terminal installed E2R.

### Procedure:

- Enter the programme's options as instructed in point 27 of the manual, then press:



- Then the following window will be displayed. Last two days' weighing results will be shown in reports window:



The screenshot shows a software window titled "Reports" with a menu bar containing "Show Report", "Keyboard", "Clear Filter", and "Choice of columns". Below the menu bar is a table with columns: "Date", "M...", "Prod...", "Operator", "Contractor", "L...", "T...", and "Platform". The table is divided into two sections: "Report 1" and "Report 2".


	Date	M...	Prod...	Operator	Contractor	L...	T...	Platform
Report 1	11/13/2009 11:4...	0.387 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1
	11/13/2009 11:01 ...	0.419 kg	Towar 1	Administr...	Kontrahe...	S 1...	0.197	1
	11/13/2009 11:01 ...	0.419 kg	Towar 1	Administr...	Kontrahe...	S 1...	0.197	1
	11/13/2009 11:01 ...	0.419 kg	Towar 1	Administr...	Kontrahe...	S 1...	0.197	1
	11/13/2009 11:00 ...	0.419 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1
	11/13/2009 10:59 ...	0.419 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1
	11/13/2009 10:59 ...	0.419 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1
	11/13/2009 10:59 ...	0.419 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1
	11/13/2009 10:59 ...	0.430 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1
	11/13/2009 10:59 ...	0.430 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1
Report 2	11/13/2009 10:59 ...	0.430 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1
	11/13/2009 10:59 ...	0.430 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1
	11/13/2009 10:59 ...	0.441 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1
	11/13/2009 10:53 ...	0.441 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1
	11/13/2009 10:53 ...	0.441 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1
	11/13/2009 10:53 ...	0.441 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1
	11/13/2009 10:53 ...	0.441 kg	Towar 1	Administr...	Kontrahe...	S12...	0.197	1


At the bottom of the window, there is a summary bar with "From: 11/12/2009" and "To: 11/14/2009".

### 27.4.1. Date

Date is the main criterion of report preparing.









#### Procedure:

- Enter reports window as instructed in point 27.4 of the manual
- Set up the initial and final calendar date, using  button placed near date field.




Calendar window will be closed after day has been chosen.

#### The fields enable following:

-  - choice of a month, button rewind , ,
-  - Year setting, button operated , ,
-  - current day quick date setting
-  - date clearing up

## 27.4.2. Laps

Using laps( **Report 1, Report 2** ) located on the left, user sets various report displaying options.




Following options can be used with laps

- column displaying order change
- column adding and eliminating from the view
- text field column filtering
- button column filtering
- increasing and decreasing column sorting

After exiting the programme, laps remain unchanged until return to default view function is used.

- **Column order changing**

To change column displaying order, a certain column's name must be pulled over and placed on another column's name. The other column from now on will follow the column we needed to replace. The example below shows replacing **mass** column in such a way that as a result **contractor** column follows it:




Date	Good	Mass	Contractor	Operator
9/30/2009 11:18 AM	Good 1	Contractor 1	2000.000	Administrator
9/30/2009 11:24 AM	Good 1	Contractor 1	2000.000	Administrator
9/30/2009 11:24 AM	Good 1	Contractor 1	2000.000	Administrator
9/30/2009 11:18 AM	Good 1	Contractor 1	2100.000	Administrator
9/30/2009 11:18 AM	Good 1	Contractor 1	2100.000	Administrator









From: 9/29/2009 To: 10/1/2009

- **Menu**

In order to get access to extended menu, you need to hold your finger a bit longer on a column.



**Note that:**

- |   |                        |  |
|---|------------------------|--|
|    | Sort ascending         | - displaying all column's lines sorted increasingly  |
|    | Sorting descending     | - displaying all column's lines sorted decreasingly  |
|   | Clear sorting          | - sorting a column's lines elimination   |
|    | UnGroup                | - grouping of displayed lines according to chosen column; dividing results in grouping elimination |
|  | Grouping field         | - switching on a grouping field, where columns' headings can be placed                             |
|   | Remove This column     | - column's displaying elimination  |
|  | Column Chooser         | - turning on adjusting window, from which eliminated columns can be drawn                          |
|  | Best Fit               | - automatic column's size matching   |
|  | Filter editing         | - starting an advanced options creator filtering   |
|   | Best fit (all columns) | - automatic matching of all columns' size  |
|  | Full Expand *          | - grouped results rewinding  |





Full Collapse \* - winding up all the results




Clear Grouping \* - elimination of grouping accessible after choosing a grouping field

\*) – options accessible if grouping field window is switched on

• **Columns filtering**

In order to filter a column’s data, write down the needed phrase in first line:





Mark the first line and press:



After having entered needed phrase, press:

Records similar to the given phrase will be displayed in the column.

After pressing button  which is located near column’s name, user can choose a filtering criterion from accessible list








In order to clear up loaded data displaying column filter, press in main window.


- **Sorting**

Sorting is possible after column or menu pressing . Sorting mode is

displayed as changing sign:  

- **Choosing columns**

Use the button  to customization window of the drag on two sides of any column.




**Available Columns:**

- Date - Date and time of weighing
- Mass - Mass unit set on the basis of the goods

Mass Gram	-	Mass of weighing in gram unit
Masa unit	-	Mass unit set in the base of the product
Unit	-	Unit set up in the database of the product
Operator	-	Operator Name
Product	-	Product name
Contractor	-	Name of contractor
Tara	-	Tara
LOT	-	LOT, batch symbol
Platform	-	Number of platform
Destination	-	The name of the target store
Max	-	Threshold for the maximum weighted product
Min	-	Threshold for the minimum weighted product
Pieces	-	Number of pieces
Product code	-	Product code
Transaction	-	Symbol transactions
Source	-	Name of the source magazine

### 27.4.3. Print monitoring


Before printing, optionally: grouping, filtering and sorting of the information displayed in window can be done. Eliminated columns will not be displayed in reports.



After having prepared appropriate report, press:



In print monitoring window, ready report view will be displayed:



**Buttons displayed in the window:**



- quick print - sending a document directly to default printer
- first page - passing on to the first report's page
- previous page - passing on to the previous report's page
- next page - passing on to the next page
- last page - passing on to the last report's page
- zoom out - zoom out in order to see larger space of the page



zoom in	zoom in in order to see enlarged part of the report
print monitoring closing	closing the report print monitoring
PDF File	- Export to PDF file format
Excel File	- Export to XLS file format
CSV File	- Export to CSV file format
Variable name file export	- Variable export file name - Constant export file name

#### 27.4.4. Export to a file

Adequately prepared the report print to a printer installed in the operating system. In the absence thereof, the report can be exported to a file in one of three available file formats, ie, PDF, XLS and CSV.

All exported reports are stored on your terminal in **C:\RadwagExport**.

With a button **Variable name file export** you can export the file name to save the report with different name which contains the date or file name to generate a constant - data.pdf, data.csv, data.xls.

#### Note:

If you select the file name has all the previously saved results are deleted and inserted in their place are new.

#### 27.4.5. Programme closing



To exit report window, press: .

#### 27.5. Others

The option enables interface view, functional buttons, language and various program's options configuration.

## Procedure:

- Enter program's options as instructed in point 27 of the manual, then press:



- Choose demanded option from **Others** window



### 27.5.1. Interface view

User can modify main program's window, that is, turning on/turning off certain elements which can be seen in the main window.

**Fields of the main screen:**

- contractor choosing button
- packing choosing button
- target store button
- source store button
- lot number loading button,
- lot 2 number loading button,
- entered quantity loading button,

**Elements of the main screen:**

- statistics windows,
- bar chart windows,

**Operating mode of the main screen:**

- transactions,
- counting pieces,
- CGM,
- Orders.

**Response - features:**

- Tarring after saving,
- Ask about product usability offset while saving,
- Clear Entered Quantity After Print,
- Autoprint.

The importance of the buttons:



- Function not active



- Function active



**Procedure:**

- Enter **Others** options as instructed in point 27.5 of the manual, then press:



- Choose elements (functions) of main program window from interface view window.

Interface			
Choice fields	Operating mode	Elements	Response
			Required    Visible
Contractor choice			<input checked="" type="checkbox"/> <input checked="" type="checkbox"/>
Source store choice			<input checked="" type="checkbox"/> <input checked="" type="checkbox"/>
Target store choice			<input checked="" type="checkbox"/> <input checked="" type="checkbox"/>
Lot number entering			<input checked="" type="checkbox"/> <input checked="" type="checkbox"/>
Lot number 2 entering			<input checked="" type="checkbox"/> <input checked="" type="checkbox"/>
Packing choice			<input checked="" type="checkbox"/> <input checked="" type="checkbox"/>
Enter Quantity			<input checked="" type="checkbox"/> <input checked="" type="checkbox"/>
			Cancel  Ok 

- In order to accept changes press: 
- In order to refuse changes, press: 

### 27.5.1.1. Choice fields

Buttons in the column **Required** select the required parameters for the right of the main window while writing manual or automatic. This is equivalent to the need to fill some fields in the main window.

Buttons in the column **Visible** meet accessibility (visibility) of the button in the main window.






### 27.5.1.2. Operating mode

Tab transactions module provides transaction activation button in the main terminal and the function of enforcing the window displays the number of record labels each time you weigh.



Counting pieces Tab provides activation counting module in the main terminal.



Tab CGM provides activation of cooperation with the camera module to study conformation in the main terminal.


CGM option to remove the data after saving measure allows for the cleaning of the information in the main window after recording.

Optional data entry required for measuring input forces from the camera when saving measure.

This option allow you to record the measurement with incorrect data for testing purposes we allow you to record a measurement with misinformation.




Orders tab allows you to order, including the module which is an extension module for transaction orders sent from the E2R transactions from your PC.



### 27.5.1.3. Elements

On the elements of statistics and activate the panel bar graph, in the main window.



### 27.5.1.4. Response

On the behavior can activate the functions performed by the program. Tarring after saving allows you to automatically tare the platform after each measurement record.


Ask to offset the suitability of the goods during the recording allows you to display a window during the recording in which the operator can extend the product's shelf. To the days of the goods listed in the database will be added to the number of days entered in the window.

Reset function introduced after the entry number allows you to remove value from the previous measurement for the number of units entered.

Autosave feature lets you record to a database of measurements without operator intervention on the panel weight.

#### **Autoprint functions:**

- Disabled** - Disabled
- Last Stable Above Lo** - Record last stable weight measurement before descending below the LO
- First Stable Above Lo** - Write the first stable measurement above the threshold LO.



## 27.5.2. Buttons' functions


User is able to configure main program's window programmable (functional) buttons.

### Procedure:

- Enter **Others** option as instructed in point 27.5 of the manual, then press:



- From **Buttons' Functions** window choose visibility of main program's window buttons.



- After choosing button's visibility, choose adequate function:

Buttons functions

	Vis.	Function	Label
F1	<input checked="" type="checkbox"/>	None	
F2	<input checked="" type="checkbox"/>	None	
F3	<input checked="" type="checkbox"/>	None	
F4	<input checked="" type="checkbox"/>	None	
F5	<input checked="" type="checkbox"/>	None	
Save	<input checked="" type="checkbox"/>	Save measurement	



Cancel Ok

- In function choosing window, choose one of accessible functions:

Function choice



<input checked="" type="checkbox"/> No	<input checked="" type="checkbox"/> Reports
<input checked="" type="checkbox"/> Statistics clearing	<input checked="" type="checkbox"/> Tare entering
<input checked="" type="checkbox"/> Record of printing a single label	<input checked="" type="checkbox"/> Lot number entering
<input checked="" type="checkbox"/> Record labels without printing	<input checked="" type="checkbox"/> Measurement saving
<input checked="" type="checkbox"/> Operator logging out	<input checked="" type="checkbox"/> Low threshold setting
<input checked="" type="checkbox"/> Operator logging in	<input checked="" type="checkbox"/> High threshold setting
<input checked="" type="checkbox"/> Mass pattern defining	<input checked="" type="checkbox"/> Transaction start
<input checked="" type="checkbox"/> Program closing	<input checked="" type="checkbox"/> Transaction ending
<input checked="" type="checkbox"/> Increasing the precision	<input checked="" type="checkbox"/> Label print

Cancel Ok

- To accept the changes, press: 
- To refuse the changes, press: 
- After having chosen button's function, enter button's label.



Buttons functions

	Vis.	Function	Label
F1	<input checked="" type="checkbox"/>	Closing application	<input type="text"/>
F2	<input checked="" type="checkbox"/>	None	<input type="text"/>
F3	<input checked="" type="checkbox"/>	None	<input type="text"/>
F4	<input checked="" type="checkbox"/>	None	<input type="text"/>
F5	<input checked="" type="checkbox"/>	None	<input type="text"/>
Save	<input checked="" type="checkbox"/>	Save measurement	<input type="text"/>

Enter label

·	1	2	3	4	5	6	7	8	9	0	- =	←
Tab	q	w	e	r	t	y	u	i	o	p	[ ]	↵
Caps Lock	a	s	d	f	g	h	j	k	l	;	'	←
Shift	z	x	c	v	b	n	m	,	/	Shift		
Ctrl	Alt									Alt	Ctrl	
←	→									cancel	ok	

- In order to accept changes press: 
- In order to refuse changes, press: 

### Accessible functions list:

- No
- statistics clearing,
- Record of printing a single label,
- Record label without printing,
- Operator's logging off,
- Operator's logging on,
- Mass pattern definig
- Closing program,
- Increasing the precision,
- Reports,
- Tare loading,
- Lot number entering,
- Measurement saving,
- minimum threshold setting,
- maximum threshold setting
- creating a transaction,
- terminating a transaction.
- Label print

### 27.5.3. Language

Program is accessible in following language versions:

- Polish
- English
- German
- French
- Czech
- Spanish


### Procedure:

- Enter **Others** option as instructed in point 27.5 of the manual, then press:





- Choose required language and accept it pressing:



**CAUTION!**

*Changing program's language version does not influence Weighing Server (weighing parameters window) or Label Editor (label designing) language versions.*

**27.5.4. Application closing**


Program's closing and passing to Windows XP Embedded operational system are accessible in other options.

**Procedure:**

- Enter **Others** option as instructed in point 27.5 of the manual, then press:



- Accept the choice in application closing window.



## 27.6. Alibi

E2R Terminal has the ability to save records of weighings in a place independent of the SQL database.

Configuration options are available for the administrator and power user has access to view content.

Weighing saved in the Alibi include:


- Time,
- Mass,
- Tare,
- Unit,
- Product name,
- Operator name,
- Contractor name,
- Serial number,
- Source stock,
- Target stock,
- Packaging.

### Procedure:

- Enter **Others** option as instructed in point 27.5 of the manual, then press:



- In the full terminal window will appear weighing Alibi memory.



- Using the Actions you access to options related to memory Alibi.



### 27.6.1. Enabling write memory Alibi

Enabling the Alibi is pressing the select button, Operations and Active record measurements as described below.

The importance of the buttons:



- Function not active




- Function active


### 27.6.2. Deleting a measurement of memory Alibi

Button to clear the complete measurements, measurements removes the set has secured days. The program allows you to record multiple measurements with the number is only limited at the time of removal.

When you delete a measurement will be displayed:



Successful removal of measurements outside the specified range will be confirmed by the message:



### 27.6.3. Export measurements alibi to a csv file

All listed measurements are saved to a file in \*. csv separated by semicolons. Each time a record will be confirmed following message.




### 27.6.4. Filter

In the main window of measurements stored in the Alibi is available filtering and grouping of records.

To this end, hit the button , and then in the window below the box indicate that you want to search and view the memory window Alibi.



Deleting a filter for a particular field means of a button  and the button below allows you to remove a filter to all fields.

## 27.7. IN/OUT configuration

For terminal equipped PUE5 derived I / O configure their operation.

### Procedure:

- Enter **Others** option as instructed in point 27.5 of the manual, then press:



### 27.7.1. Inputs configuration


On the input we can assign a specific function to the selected input depending on its activation or deactivation. The assignment of the input is activated by pressing work or until you reach the input signal. The assignment of the work input is activated when the button is released, or when the input signal disappears.

IN / OUT		
Inputs	Outputs	Other
Enabling	Disabling	
Input 1	Disabled	Disabled
Input 2	Disabled	Disabled
Input 3	Disabled	Disabled
Input 4	Disabled	Disabled

Cancel Ok

The list of available functions assigned to the input:

- Disabled,
- Tarring,
- Zeroing,
- Increased accuracy,
- Print.




### 27.7.2. Outputs configuration

On the output assign specific functions activating or inactivating the selected output. The assignment of the output activation will produce a signal at the output. The assignment of the deactivation of the output will disable the output.




The list of available functions assigned to the input:

- Disabled
- Mass first stable > LO
- Mass below LO
- Mast last Stable > LO
- Mass over LO
- After saving measure
- Stable
- No Stable



### 27.7.3. Other options

On the other options are available concerning the terms of inputs / outputs that can make the operator from having to log in, or completion of all required data.






# 28. CONFIGURATOR PROGRAM


## 28.1. Basic Configuration

Terminal to Terminal PUE5 E2R records that has the settings allow you to work in the local SQL database.


If the terminal is designed for networking, need to change the factory settings. To run the setup file Config.e2r delete the folder **C:\Program Files\RADWAG\Terminal E2R Ewidencja** in the file that contains all the necessary terminal settings.




In the following startup screen, press




The next window allows you to enter server parameters and settings.



**Where:**

Server	-	Name or IP of the server and SQL instance E2R SYSTEM works for instance BAZARADWAG
Database	-	The name of the database, by default <b>E2R</b>
Login	-	Login to the SQL database, by default <b>sa</b>
Password	-	The password for the SQL database, by default <b>radwag</b>
	-	Button for checking the connection to the set parameters of the database.


Window proper connection to the database.



Window indicating that the lack of connection to the database.




The window definition ID for terminal, which is unique in the case of terminal operation in the system E2R. Once fully configured, restart the program.




## 28.2. External configuration

In parallel with basic configurator that runs when the file is missing Config.e2r in the program folder. EwPue5Settings.exe program is available in the program folder.



In the configuration, get access to change the parameters stored in a config.e2r - number, weight and data on the SQL database.


Window settings SQL database.



Where:

Serwer	-	Name or IP of the server and SQL instance E2R SYSTEM works for instance BAZARADWAG
Baza danych	-	The name of the database, by default <b>E2R</b>
UserID	-	Login to the SQL database, by default <b>sa</b>
Hasło	-	The password for the SQL database, by default <b>radwag</b>


The settings window of the terminal.



Where:

Terminal ID	-	ID of another terminal in the database, you must have a unique number to the network at work.
-------------	---	---

Options for loading and saving configuration can be found in the Configuration menu.



**Where:**

Wczytaj aktywną	-	Load configuration from file Config.e2r
Wczytaj bieżącą	-	Load re-opened for the configuration of the (active) file
Wczytaj z pliku	-	Load configuration from the selected file
Zapisz aktywną	-	Writing configuration settings to a file Config.e2r
Zapisz bieżącą	-	Writing configuration settings to the opened for the (active) file
Zapisz jako	-	Writing configuration settings to the selected file

Terminal E2R Records is working on the active configuration file Config.e2r. Created configuration files with the extension \*. e2r may be downloaded and saved as the active configuration.

## 29. WEIGHING PARAMETRES SETTING


User can change basic weighing setting using **Weighing Server** program.

### 29.1. Weighing Server program starting

Start scale software as instructed in point 27.1 or proceeding as follows:


- Press the **START** button on the bottom taskbar,
- press **Programs**,
- press **RADWAG**,
- press **Weighing Server**, click it

Window program **Weighing Server** will be open:




## 29.2. List of software menu


Hold finger for about 2 s on scale software window, menu list of accessible software will be displayed:



## 29.3. Parameters of scale software


### 29.3.1. Readout of parameters

To read out scale parameters press: , scale software will indicate parameters list accessible for edition:



### 29.3.2. Save changes procedure

After having changed the parameters, save the values by pressing:


. When saving procedure is finished scale software will display message:



## 29.4. Setting a filtering level

### Procedure:

- Readout parameters according to point 29.3.1 of the manual,
- Press and rewind **Filter** parameter value window.



After selecting required parameter value save changes according to point 29.3.2 of the manual.

### **Notice:**

*The higher filtering level the longer scale stabilization time.*


## 29.5. Median filter

This filter eliminates short pulse disturbances (for example: mechanical shocks).

### Procedure:

- Readout parameters value according to point 29.3.1 of the manual,
- Press and then rewind “Median Filter” parameter value window.






After selecting the required value save changes according to 29.3.2 of the manual.

## 29.6. Autozero function

The autozero function has been introduced in order to assure precise scale's indications. This function controls and corrects „0” indication. While the function is active it compares the results successively with constant frequency. If results differ less than the declared value of autozero range, for example 1unit, the scale will be automatically zeroed and the stability result markers  $\blacktriangleleft$  and zero indicator  $\rightarrow 0 \leftarrow$  will be displayed. When AUTOZERO function is active, each measurement starts with precise zero. In particular cases the function can disturb measuring process. For example when product is loaded very slowly on scale pan (pouring), **Autozero** system can influence real weighing results.

### Procedure:


- Readout parameters value according to 29.3.1 of the manual,
- Press, then rewind **Autozero** parameter window.



After selecting the required parameter value save changes according to 29.3.2 of the manual.

## 29.7. Scale software settings

After starting program menu list (see point 29.2 of manual) press with finger option **<Settings>**:



Scale software will display settings window:



Accept change of parameters value with key: .

**Notice:**

Additional weighing platform module MW02 is working on port **COM2**.


Languages available:

- Auto - Setting language version compatible with the version of the operating system.
- Polish
- English
- German

Set the address track to the software keyboard on:

C:\Program Files\screen keyboard\KEYBOARD\_mini.exe

### 29.8. Closing WeighingServer program

In order to exit the program press the button:  on the main window.

## 30. ERROR MESSAGES


- Err2** - Value beyond zero range
- Err3** - Value beyond tare range
- Err8** - Exceeded time of tarring / zeroing operation
- null** - Converter zero value
- FULL** - Measurement range exceeding
- LH** - Initial mass error, indication beyond (from -5% to +15% range of initial mass)

## 31. LABEL DESIGNING

Computer program **EDYTOR ETYKIET R01** is used for label patterns making. First a label pattern is saved as a file with “**lb**” extension, then it is set in Terminal E2R Ewidencja program.

## Example:

Setting in a scale a pattern adequate for the following label:




### 31.1. Label pattern making

#### Procedure:


1. Start **EDYTOR ETYKIET R01** computer program as instructed in point 29.3.2. or operational system according to the following description:
  - press **START** on the bottom task bar
  - indicate **Programs** option,
  - choose **RADWAG** option,
  - choose **Edytor Etykiet R01**,
  - click **Edytor Etykiet R01** symbol.
2. While starting, the following window will appear:





3. Choose type of printer connected with scale, press:








then the main program's window will be displayed





4. In order to add text to a label, click  on the left task bar, then following window will be displayed



5. Start the keyboard pressing:  located in top right part of the screen.
6. In **<Text>** space enter the text: Meat Plant „MEATON”, accept with  and place it on label using appropriate type size.


7. Click again on  and in the window „Enter text” insert **{4}**, and confirm by pressing  and place the required variable in the right place on the label,
8. Place other constant texts and demanded variables on the label as instructed above.
9. Click  and in „Load graphics” window rewind **<Graphics>** list:





10. Choose required **<\*.bmp>**, accept with  and put graphics in appropriate label place

**Caution:**

**<\*.bmp>** located on label will be printed after the graphics have been sent to printer's memory. Description of data sending to printer can be found in Help/program options/Sending to printer lap in computer program's menu.

11. Click  and rewind **<Code Type>** list in “Enter bar code” window, choosing **< EAN-13>**.



12. Using keyboard enter variable in **<Codebar value>** space **{52}**.
13. Accept changes with  and put a code in appropriate label place.
14. Save ready label pattern choosing **<File>**, then **<Save as...>** lab.
15. Set up a label in Terminal E2R Evidence application as instructed in point 27.3.2. of the manual.

**Caution:**

*Saved label pattern with **\*.lb** extension is not editable file. Therefore additional label pattern recording with **\*.lab** extension is recommended (program's menu: File/ Save as...) in order to enable future label pattern modification.*

### 31.2. Inventory of variables:

The list of all variables accessible in the system for defining label patterns in program Terminal E2R Ewidencja from version **1.1.6.118**

Symbol	Description
{2}	Date
{3}	Time
{4}	Date and time
{6}	Net mass in the current unit
{7}	Net mass in calibration unit
{8}	Gross mass
{9}	Tare
{10}	Current unit
{11}	Calibration unit
{12}	Minimum threshold
{13}	Maximum threshold
{14}	Batch number
{25}	Hex
{26}	HexToUTF8
{27}	Net value
{30}	Gross value

{31}	Platform number
{35}	Counting pieced: unit mass in calibration unit
{48}	Product: Temperature
{49}	Product: Description
{50}	Product: Name
{51}	Product: Code
{52}	Product: EAN code
{53}	Product: Mass
{54}	Product: Tare
{55}	Product: Unit price
{56}	Product: Minimum
{57}	Product: Maximum
{59}	Product: No of validity days
{60}	Product: VAT
{62}	Product: Expiry date
{64}	Product: ingredients or any other additional information
{65}	Contractor: Name
{66}	Contractor: Code
{67}	Contractor: Tax ID
{68}	Contractor: Address
{69}	Contractor: Postal code
{70}	Contractor: City
{71}	Contractor: Discount
{75}	Operator: Name
{76}	Operator: Code
{77}	Operator: Authorization level
{80}	Package: Name
{81}	Package: Code
{82}	Package: Mass
{85}	Source warehouse: Name
{86}	Source warehouse: Code
{87}	Source warehouse: Description
{90}	Destination warehouse: Name
{91}	Destination warehouse: Code
{92}	Destination warehouse: Description
{300}	LOT 2
{301}	Entered Quantity



In counting pieces variable {6} „Net mass in present unit” presents the number of pieces {10} the current unit is “pcs”.

In case of variable {64}, each line (L1-Ln) is formatted according to the pattern:


Line 1 – {64:L1}, Line 2 {64:L2}, etc.

## 32. DIAGRAMS OF CONNECTION CABLES


The scale in **STANDARD** version can cooperate with:

- computers
- slip printers KAFKA, EPSON, KYOLINE
- label printers CITIZEN, ZEBRA,


### 32.1. USB cable (adapter)



### 32.2. USB printer cable




### 32.3. RS232 printer cable




RS232 printer (CITIZEN, EPSON) cable PT0019.

### 32.4. Ethernet cable




Ethernet cable P0198:

### 32.5. RS232 terminal – computer cable




RS232 terminal – computer cable PT0020

### 32.6. RS232, RS485 cable – colours



Colours for "M12" standard cables. The figure gives an example of the type of cable.

### 32.7. RS232C cable – colours



Colours for "M12" standard cables. The figure gives an example of the type of cable.


## 33. CONNECTORS

### **Caution:**

Depending on the number of installed additional modules the number and location of glands and connectors can change. Standard option connectors and glands' location does not change.

### 33.1. RS232, RS485 connector

pin1 - B  
pin2 - RxD  
pin3 - TxD  
pin4 - A  
pin5 - GNDRS  
pin6 - +5VDC



**RS232**  
**RS485**

*(plug in side view)*

### 33.2. Ethernet connector


pin1 : RX+  
pin2 : TX+  
pin3 : RX-  
pin4 : TX-



*(plug in side view)*

### 33.3. USB connector


pin1 - VCC  
pin2 - D-  
pin3 - D+  
pin4 - GND



*(plug in side view)*

### 33.4. RS232C connector

pin1 - DCD  
pin2 - RxD  
pin3 - TxD  
pin4 - DTR  
pin5 - GND  
pin6 - DSR  
pin7 - RTS  
pin8 - CTS



*(plug in side view)*

## 34. SPECIFICATION OF ADDITIONAL MODULES

Apart from standard interface, it is possible to equip terminals PUE 5 with additional module increasing functionality of devices:

- Weighing module **MW-02**
- 8 inputs / 8 outputs module **WE 8**,
- 4 inputs / 4 outputs module **WE 4**,
- Analogue output module of **AN** series,
- Interface Profibus **DP V1**.

### 34.1. Weighing module MW-02

The weighing module MW-02 is responsible for the whole process of weighing. It is supplied with factory parameters and scale parameters (filters, units, etc.) memory. It is installed in the main board of PUE 5. The module is supplied with factory parameters access button. The button is protected with a seal.

Factory parameters are protected and can be accessible only after pressing the calibration switch on the module during powering up. The module is totally covered by the shield together with the calibration switch and soldering pads of load cell.

The calibration switch is accessible through the hole in the shield and can be additionally sealed with an external sticker.



*Weighing module MW-02*

### 34.1.1. Module technical specification

Maximal number of convertor units	8 388 608
OIML class	III
Number of verification units	6000e
Maximal signal gain	19mV
Maximal voltage per verification unit	3,3 $\mu$ V
Minimal voltage per verification unit	1 $\mu$ V
Minimal strain gauge impedance	90 $\Omega$
Maximal strain gauge impedance	1200 $\Omega$
Strain gauge converter supply voltage	5V
Strain gauge converters connection	4 or 6 wires + shield


### 34.1.2. Weighing platform signal wires colours

<b>Strain gauge sensor determiners</b>	<b>Colours according to the RADWAG standard</b>	<b>Weighing module determiners</b>
+INPUT	brown	+5V
-INPUT	green	AGND
+OUTPUT	yellow	+IN
- OUTPUT	white	-IN
+SENSE	gray	+REF
- SENSE	pink	- REF
SCREEN	yellow-green	(according to the rule of connecting shields)

### 34.1.3. Weighing platform connecting

- **6-wire strain gauge sensor platform connection**


6-wire strain gauge sensor can be connected to weighing module board as instructed below:



WEIGHING MODULE SIGNAL	STRAIN GAUGE SENSOR SIGNAL	NOTICE
E	SCREEN	(according to the rule of connecting shields)
REF+	SENSE +	JP1 not soldered
REF-	SENSE -	JP2 not soldered
IN+	OUTPUT+	
IN-	OUTPUT-	
+5V	INPUT+	
AGND	INPUT-	

- **4-wire load cell cables**

For 4-wire load cell cables look at the drawing below:



SIGNAL FROM WEIGHING MODULE	SIGNAL FROM TENSOMETER	NOTICE
E	EKRAN	(according to the rule of connecting shields)
REF+	-	(JP1 solder)
REF-	-	(JP2 solder)
IN+	OUTPUT+	
IN-	OUTPUT-	
+5V	INPUT+	
AGND	INPUT-	

- **Connection of strain gauge cable shield**


	With connection between the shield and the load cell body (manufacturer feature)	Without connection between the shield and the load cell body (manufacturer feature)
The scale with housing or stainless connected with the platform via cable.	<b>POINT B</b>	<b>POINT B</b>
Compact mechanical construction of the scale (e.g. a scale with the indicator on the pillar )	<b>POINT B</b>	<b>E</b>

**Point B** – screwed terminal electrically connected to the housing  
**E** – soldering point on the main board

**The way of checking connection between the shield and the tensometer body.**

Use an ohmmeter for this purpose.






### 34.1.4. The way of installing inside PUE 5

Module is designated for assembly inside terminal PUE5. Module with **address 1** is assembled to main board of terminal to **J13(Slot 0)**, module with **address 2** is assembled to connector **J11 (Slot 1)**. For the second module **MW-02** gland is installed on casing lid, 3m cable ended with insulated conductors is led through gland.

#### Installing procedure:

1. Unplug the terminal (remove the plug from socket 230V);
2. Unscrew the casing lid (back part of terminal casing);
3. Install the module in connector J13 or J11 on main board, depending on it's address;



*Installation of the module MW-02 on the motherboard terminal PUE 5*

Pcs.	Component name
1	Motherboard
2	Weighing module
3	Round ferrite core
4	Ferrite core

4. While installing the module in the plastic socket on the main board turn you attention to the position of the module (see the figure below),



5. The strain gauge cable led through additional gland PG7 situated on the back wall next to the gland of the main platform cable;
6. Pull a ferrite core on the cable (appropriate internal diameter);
7. Wind wires of the cable on the round ferrite core (5 coils);
8. The wires solder accordingly to pads on the PCB. **USE A SOLDERING IRON (not a solder gun with a transformer);**
9. Connect cable IN/OUT to group of conductors (undo band clips fastening group of conductors, lay the cable and clamp band clips – multiple use band clips);
10. Assembly cover of indicator casing.

### 34.2. Additional 8 inputs / 8 outputs module



*8 inputs / 8 outputs PCB - WE 8*

This module can be connected inside the weighing terminal. Its task is to expand the functionality of terminal for 8 inputs and 8 outputs freely configurable.

### 34.2.1. Technical specification

Parameters of outputs	
Quantity of outputs	8
Type of outputs	Reed operation contacts
Wire diameter	0,14 - 0,5mm <sup>2</sup>
Maximal load-current contact capacity	0,2A DC
Maximal forward voltage	50V DC


Parameters of inputs	
Quantity of inputs	8
Input type	Optoinsulated
Wire diameter	0,14 – 0,5mm <sup>2</sup>
Control voltage range	5 -24V DC

### 34.2.2. Installing method in PUE 5 terminal


Module is designated for assembly inside terminal PUE5. Module is assembled to main board of terminal to 10-pin **J22** connector. For module **WE8** gland is installed on casing lid, 3m cable ended with insulated conductors is led through gland.

#### Installing procedure:

1. Unplug the terminal (remove the plug from socket 230V);
2. Unscrew the casing lid (back part of terminal casing);
3. Install the module in connector **J22** on main board;
4. While installing module pay attention to plastic posts fastening to main board. They should be placed in assembly holes in main board and in assembly holes in module WE 8,
5. In one of free glands remove the stopper and led through it cable IN/OUT (if necessary use bigger gland depending on cable diameter);
6. Connect the cable IN/OUT to joint **J1**, **J2** for outputs and **J3**, **J4** for inputs on module 8IN/8OUT according to description given in table;
7. Connect cable IN/OUT to group of conductors (undo band clips fastening group of conductors, lay the cable and clamp band clips – multiple use band clips);
8. Assembly cover of indicator casing.



### 34.2.3. I/O diagram



*WE8 inputs diagram*

*WE8 outputs diagram*

### 34.2.4. Description of input output wires PT0082:

SIGNAL	LEADS NUMBER (FOR JZ-500 18G0,5)
IN 1	1
IN 2	2
IN 3	3
IN 4	4
IN 5	5
IN 6	6
IN 7	7
IN 8	8

GND IN	9
OUT 1	10
OUT 2	11
OUT 3	12
OUT 4	13
OUT 5	14
OUT 6	15
OUT 7	16
OUT 8	17
COMMON	(18) YELLOW GREEN

### 34.3. WE 4 - 4 inputs / 4 outputs module

**WE 4** module comprises 4 optoinsulated inputs and 4 optoinsulated outputs of reed relays, does not require installing additional modules on the main board of the terminal. The input / output wires are led out via a gland on the back wall of the housing (3m length).

#### 34.3.1. Technical specification

<b>Parameters of outputs</b>	
Quantity of outputs	4
Type of outputs	Reed operation contacts
Wire diameter	0,14 - 0,5mm <sup>2</sup>
Maximal load-current contact capacity	0,2A DC
Maximal forward voltage	50V DC
<b>Parameters of inputs</b>	
Quantity of inputs	4
Input type	Optoinsulated
Wire diameter	0,14 – 0,5mm <sup>2</sup>
Control voltage range	5 -24V DC

### 34.3.2. Colours of cables for I/O PT0083:


SIGNAL	LEADS NUMBER (FOR JZ-500 108G0,5)
IN 1	1
IN 2	2
IN 3	3
IN 4	4
GND IN	5
OUT 1	6
OUT 2	7
OUT 3	8
OUT 4	9
COMMON	(10) YELLOW GREEN

### 34.3.3. Installing method in PUE 5 terminal

**WE 4** modules are equipped in one cable, for inputs and outputs.


#### Installing procedure:

1. Unplug the terminal from mains;
2. Unscrew and take off the back wall of the housing;
3. Install a PG9 gland and led cable **PT0083** through it;
4. Connect the **PT0083** cable to the **J24** connector for inputs or to the **J23** for outputs, on the main board of PUE 5.
5. The cable connect to the group of wires (unhook band clips fastening the group of wires, lay the cable and hook the band clips). Band clips of multiple usage;
6. Screw down the back wall.



*Installing WE4 modules on the main board of PUE 5*

## 34.4. Analogue output module AN series



*Module of analogue outputs*

### Module accessible in three configurations:

- Voltage output **AN 0-10V**
- Current output **AN 4-20mA**
- Current output **AN 0-20mA**

#### 34.4.1. Technical specification

Work modes	4 - 20mA , 0 - 20mA, 0 - 10V
Resolution	16 bit
Current output resistance	<500 $\Omega$
Voltage output resistance	>400 $\Omega$
Power supply	24V DC (12 - 30V DC) max 40mA


#### 34.4.2. The way of installing inside PUE 5

These modules are intended to mount inside PUE 5. They need to be connected to the 10-pin J22 connector. For all configurations of AN, there is a gland installed on the back wall of the housing. A 3-meter shielded cables are led out via the gland. Wires should be free from insulation.

#### Installing procedure:

1. Unplug the terminal from mains;
2. Unscrew and take off the back wall of the housing;
3. Install your module in J22 on the main board;

4. During installation turn your attention to plastic columns. They should be placed one side in mounting holes in the main board and the other side in the mounted module;
5. Led the PT0015 cable through one of the free glands;
6. Connect the PT0015 cable to J3 on the analogue module according to the description below;
7. Connect the PT0015 cable shield to the housing (screwed terminator, 4mm diameter);
8. The cable connect to the group of wires (unhook band clips fastening the group of wires, lay the cable and hook the band clips). Band clips of multiple usage;
9. Screw down the back wall.



MODULE CONFIGURATION

R1	R2	Operation mode
0	0	0-10V
0	1	4-20mA
1	0	0-20mA
1	1	0-24mA

Mounting of **AN** module on the main board of PUE 5


### 34.4.3. Configuration of work modes of analogue modules

A work mode of analogue modules can be set using **S1** switch according to the drawings above (table „*configuration of analogue modules*”). Near the **S1** switch on the PCB you can find a description




### 34.4.4. Connections to AN module

Drawing of connections of voltage output:



COLOURS OF WIRES	
Colour	Signal
Pink	$U_{OUT} +$
Gray	GND
Yellow	+24V DC
Green	GND


Drawing of connections of current loop:



COLOURS OF WIRES	
Colour	Signal
White	$I_{OUT} +$
Gray	GND
Yellow	+24V DC
Green	GND

#### PT0015

#### Analogue outputs' cable



Cable for analogue output

### 34.5.Profibus interface DP V1



*Profibus Plug-In Module*

PUE5 weighing terminals can be optionally equipped in Profibus Plug-In Modules of DPV1 standard with connectivity via the uniform **Anybus-CompactCom**. A detailed description of the interface is in a separate manual Profibus PUE5.

#### 34.5.1. Technical specification

Size	52mm x 50mm x 22mm
Power Supply	3,3 V DC
Temperature	-10 do +40°C
BUS Baud Rate	Auto Baud Rate
I/O Input	244 bytes(Max 368 bytes IN+OUT)
I/O Output	244 bytes (Max 368 bytes IN+OUT)
Appl Interface	serial
Internal baud rates	19.2; 57.6; 115.2; 625 kbps (internal DIP SWITCH)
Baud Rate Error	±1.5%

#### 34.5.2. Colours of wires


A	Green
B	Red

#### 34.5.3. The way of installing inside PUE 5


These modules are intended to mount inside PUE 5. They need to be connected to the **J9**. There is a gland installed on the back wall of the housing. A 3-meter shielded cables are led via the gland. Remove insulation from wires.

## Installing procedure:

1. Unplug the terminal from mains;
2. Unscrew and take off the back wall of the housing;
3. Install your module in **J9** on the main board;



4. Screw down the interface using 2 screws;
5. Set the DIP-SWITCH **DP1** (RS485 – CF MODULES) in position OFF,



Switch settings **DP1**:

1 – ON



6. Set **SW1** to 115,2 kbs.,

SPEED	OM2	OM1	OM0	SW1
19,2kbps	OFF	OFF	ON	<input checked="" type="radio"/> OM2 <input type="radio"/>
57,6kbps	OFF	ON	OFF	<input type="radio"/> OM1 <input type="radio"/>
115,2kbps	OFF	ON	ON	<input type="radio"/> OM0 <input type="radio"/>
625kbps	ON	OFF	OFF	ON OFF

Switch settings **SW1**:

- 1 – ON
- 2 – ON
- 3 – OFF



- 7. Connect socket SUB-D with a cable,
- 8. Remove the hole plug from one of the free glands and led the cable through;
- 9. The cable connect to the group of wires (unhook band clips fastening the group of wires, lay the cable and hook the band clips). Band clips of multiple usage;
- 10. Screw down the back wall.
- 11. Set in the MS Windows Device manager, USB serial port on **COM4**

### 35. ADDITIONAL EQUIPMENT

- |                                     |  |
|-------------------------------------|--|
| Additional weighing platform module | - Metrological parameters as for main platform |
| In / out module                     | - Additional 8 in / out                        |
| Profibus DP V1 interface            | - Slave working mode                           |

## 36. TECHNICAL PARAMETERS

<b>Technical data:</b>	<b>TMX/E 1,5/3/H1</b>	<b>TMX/E 3/6/H1</b>
Maximal capacity	1,5/3 kg	3/6 kg
Minimal load	10 g	20 g
Readability	0,5/1 g	1/2 g
Tare range	-3 kg	-6 kg
Pan size	150x200 mm	
Working temperature	0° - +40° C	
Output signal	2 x USB (load carrying capacity 500mA), RS 232C, RS 485, Ethernet, 4 inputs, 4 outputs	
IP rating	IP67 indicator	
Power supply	85-265 VAC 50-60Hz	
Power consumption	45W	
Display	LCD 12,1" (800x600) infrared controled panel	
Net weight / Gross weight	12,5/14,5 kg	
Package dimensions	indicator 470x350x250 mm platform 520x260x290 mm	

<b>Technical data:</b>	<b>TMX/E 1,5/3/H2</b>	<b>TMX/E 3/6/H2</b>	<b>TMX/E 6/15/H2</b>	<b>TMX/E 15/30/H2</b>
Maximal capacity	1,5/3 kg	3/6 kg	6/15 kg	15/30 kg
Minimal load	10 g	20 g	40 g	100 g
Readability	0,5/1 g	1/2 g	2/5 g	5/10 g
Tare range	-3 kg	-6 kg	-15 kg	-30 kg
Pan size	250x300 mm			
Working temperature	0° - +40° C			
Output signal	2 x USB (load carrying capacity 500mA), RS 232C, RS 485, Ethernet, 4 inputs, 4 outputs			
IP rating	IP67 indicator			
Power supply	85-265 VAC 50-60Hz			
Power consumption	45W			
Display	LCD 12,1" (800x600) infrared controled panel			
Net weight / Gross weight	14,5/16,5 kg			
Package dimensions	indicator 470x350x250 mm platform 580x320x360 mm			

### 37. APPENDIX A – SETTING A BARCODE SCANNER

1. RADWAG scales use RS232 interface with transmission in one direction to communicate with a barcode scanner. It requires only two wire connection. So barcode scanners needs to be equipped with RS232 with disabled hardware and software flow control.
2. Both the terminal and a scanner can have transmission parameters set. Both devices should have set the same parameters: baud rate, data bits, parity control, number of stop bits. e.g. 9600,8,N,1 – baud rate 9600 bit/s , 8 - data bits, no parity control, 1 stop bit. By default in PUE5 barcode scanner needs to be connected to COM3 – with baud rate 9600 bit/s.
3. Barcode scanners can send additional information apart from a barcode e.g. barcode symbology. As RADWAG devices do not use this information it is advisable to disable it.
4. Some RADWAG systems can omitted some inessential information in the code by setting parameters outlining the beginning and length of the analyzed code.
5. In order to have a barcode read by PUE5 it is required to program an appropriate prefix and suffix. The prefix is (1 byte) 01 hexadecimally and the suffix is (1 byte) 0D hexadecimally.
6. Different barcode scanners allow to disable/enable reading different barcode symbologies.
7. Barcode scanners can be programmed by reading different programming codes present in their programming manuals.
8. Barcode scanners bought together with RADWAG systems are properly configured and tested.

<b>Barcode coded hexadecimally with prefix and suffix</b>	<b>Barcode in ASCII code (omitted control characters)</b>	<b>Symbology</b>
01 30 30 32 31 30 31 32 36 0D	00210126	EAN-8
01 30 31 32 33 34 35 36 37 38 39 0D	0123456789	2 of 5
01 43 4F 44 45 20 33 39 20 54 45 53 54 0D	CODE 39 TEST	CODE 39
01 31 31 30 31 32 33 34 35 36 37 38 39 31 0D	1101234567891	EAN-13
01 43 6F 64 65 20 31 32 38 20 54 65 73 74 0D	CODE 128 Test	CODE 128

**PRODUCENT**  
WAG ELEKTRONICZNYCH



RADWAG WAGI ELEKTRONICZNE  
26 – 600 Radom, Bracka Street 28

Main line tel. +48 48 38 48 800, tel./fax. + 48 48 385 00 10  
Selling department + 48 48 366 80 06  
[www.radwag.pl](http://www.radwag.pl)



DIN EN ISO 9001:2000  
CERTIFICATE NO 71 100 C206